TSLOPE User Guide

1. Introduction

On starting TSLOPE a four-panel interface is displayed. This allows for:

- a project navigation tree (top left) with stipulated items.
- an item panel (middle left), which is a context sensitive panel that changes based on your selected item in the navigation tree and provides either user defined input parameters or a help panel. This will sometimes be referred to by the item name, for example materials panel if you have selected Materials in the navigation tree. Note that you may need to scroll down to see the full panel, where possible it has been divided into sections that can be opened/closed by toggling the +/- box in the left margin.
- a logging panel (bottom left) that provides information on TSLOPE processing activity.
- a graphics panel (right) which provides tabs at the base for 3D interactive graphics and report snapshots. This panel begins with just a Project tab at the top, and new tabs will appear as each new Slope Case is defined.



If desired the panel sizes can be adjusted by hovering the mouse over the intersection between panels until a double ended arrow appears – you can then left mouse click and resize.

There is also a menu bar and tool bar across the top and a status line across the bottom. The status line will show a progress bar while things are processing and coordinates of your mouse pointer within the graphics panel.

The *File* menu from the menu bar, enables the usual options such as a new project to be setup or an existing project to be opened.

Your TSLOPE project can be setup to run various slope cases or scenarios. The properties, surfaces, layers and zones can be defined for use in one or many of the slope cases. Any given slope case may only use one of: one material, or layers, or zones.



A strength can also be assigned to a basal surface.

2. Orientation and Navigation in the Graphics panel

The 3D axis of the graphics panel is created with the following assumptions:

X axis runs horizontally east west and increases to the east

- Y axis runs horizontally north south and increases to the north
- Z axis runs vertically and increases upwards

Viev	v Help
~	View Axes
~	View bounding box
1	Top (⇒ -Z)
	Bottom (= +Z)
	$E \Rightarrow W (\Rightarrow -X)$
	$W \Rightarrow E (\Rightarrow +X)$
	$N \Rightarrow S (\Rightarrow -Y)$
	$S \Rightarrow N (\Rightarrow +Y)$
	Zoom Extents
	Perspective
•	Parallel
	Сору
	Save view
1	Export surfaces
	Export scene

In the *View* menu at the top, you will find options to display the axes and bounding box. You can also zoom to predefined views from the top, bottom, east, west, north and south. These can be displayed parallel or in perspective. The zoom extents option will resize your current viewing orientation and show the full extent of your project.

Your viewing orientation can also be adjusted manually using the mouse buttons: **Rotating** (3D views only)

Left click – click at a point and hold the button down, then move that point to its new location and release the button.

Panning

Middle click (or Shift-Left click) – click at a point and hold button down them move that point to its new location and release.

Zooming

Right click – click at a point and hold button down then move mouse upwards to zoom in or downwards to zoom out.

(2D view option) Left click – click at first corner, hold button down and move to diagonally opposite corner and release.

Hot keys (these work in both upper or lower case)

W = change graphics to wireframe view (from surface)

S = change graphics to surface view (from wireframe)

- R = zoom graphics to extents
- P = display point information

Note that the X coordinates shown on the 2D Slope Case view are not the same as the project coordinates. The X displayed is the horizontal offset from the origin of the Cross-section. Further details of the Cross-section location can be obtained from the Cross-sections menu (start and end points, bearing, length).

3. Setup

When starting a new project check each item in the navigation tree. Beginning with the first item - *Title & Description*. This is a useful place to document the location and reason for the analysis, especially if sharing with colleagues.

Preferences

TSLOPE					
File Edit View Help					
	P 📶 🔋 🖻 📫				
 TSLOPE Title & Description Preferences Materials Surfaces Layers Zones Cross-sections Slope Cases 					
E Project					
Units	Metric				
Weight of water (kN/m3)	9.8				
Atmospheric Pressure (kPa)	101.3				
Project Clipping					
Enable clipping	False				
Graphics					
Background colour	White				
Contours					
Definition	auto				
Interval (m)	10				
Export HTML Report					
Embed Images	False 🗸				

In the *Preferences* input panel, the Units may be defined as Metric or U.S. Customary by activating the tag on the right side the Units cell. There is no automatic conversion of values when the units label is changed, but it is a reminder to the user to enter appropriate values e.g. metric values will be kPa, m, and kN/m³ while U.S. Customary will be psf, ft, pcf. Note that the Units cannot be changed once you have created your first surface.

There are default values for the 'Weight of water' and 'Atmospheric Pressure'. The unit weight of water is required if a phreatic surface is defined and the atmospheric pressure is required for the curved Mohr-Coulomb failure criterion. Both these values can be changed if required.

Project clipping is used where you have imported various surfaces with different extents. This makes it easy to export from another system and then to trim them all back to the area where you want to create a model. Note that you do not need to know anything about project limits when you start off - this is a way to clip it all back to something sensible after you have imported or created your surfaces. When Project clipping is toggled to True, 6 nodes will be displayed in your graphic window at the current extents of the data – these can be adjusted graphically to trim the project to your area of interest. When you have adjusted in all directions you can tick the Clicking is Locked to save your settings and hide the nodes.

By default, the background colour in the graphics panel is white but this can be changed by left mouse clicking in colour cell to activate the Colour Chooser dialog box. Note that by default top surfaces will be coloured green, basal surfaces will be coloured brown and phreatic surfaces will be coloured blue, you should therefore select a contrasting colour if you are changing the background.

Contours – this is the contour interval for display on your surfaces, it is automatically set and is based on the vertical range of your surfaces. It will default to a round number of units so that there are not too many or too few contours displayed.

Export HTML Report-Embed Images. This option allows you to toggle between True and False to embed images (from your Report Snapshots tab) into your HTML report which is created using File > Export HTML.

True will embed any images into your HTML file, whereas False will read and display them from your temporary memory. If you are going to share the HTML report with colleagues you will need to embed the images.

Note that the HTML report with embedded images will display correctly in modern web-browsers, but not in MS Word. If you require the report in MS Word you can use these options:

- Set embed images to False, export the HTML and open it in Internet Explorer, from there File-Save as and select option 'Web Archive, single file (*.mht)'. MS Word will read this format and retain the images.
- Set Embed images to False, export the HTML and open on the same computer in MS Word, from there use File-Save as and select 'PDF (*.pdf)'

Proceeding down the navigation tree the next part of the setup involves defining the Material properties.

Materials

A material defines the weight and failure criterion properties for a soil or rock. The default material is used to initialise new additional materials. If only one material is required for the set of slopes, only the default material needs to be defined. A material may be assigned to a layer, zone or a basal surface.

Layers and Zones

If the material properties vary spatially, material properties may be assigned to either layers, or zones.

Layers define material properties within discrete stratigraphic layers. A Layer surface defines the top of the strata, with the material properties constant vertically downward until the next Layer surface is encountered.

A Zone is defined by a horizontal polygon and defines a vertical polygonal column with one assigned material.

Both layers and zones can be defined in a project, although this would be unusual. A slope case may only use one of: one material, or layers, or zones.

Basal Surface Materials - Strength Properties Only

There is an option to assign a material to a basal failure surface. In this case only the strength properties are used, and the weight of soil above the failure surface is determined by either Layers or Zones, or One material.

For the Basal surface material option to be enabled, a material must be assigned to a basal surface, and in the Slope Analysis properties the option 'Use basal surface material strengths' must be set to True.

 TSLOPE Title & Description Preferences Materials Surfaces Layers Zones Conss-sections Slope Cases 				
Material Anisotropy				
Material				
ld	0			
Label	Default			
Failure criterion	Mohr-Coulomb ~			
Unit Weights				
Unsaturated	16 kN/m ³			
Saturated	18 kN/m ³			
Mohr-Coulomb				
Cohesion function	Constant			
Cohesion	0 kPa			
Angle of friction	10 °			
E Colour				
Colour	(117,211,150)			

Clicking on the *Materials-Default* item in the navigation tree will display the preset values for slope stability analysis in the *Material* input panel.

Moving to the *Material* input panel and clicking on the Label cell enables the material name to be changed to the appropriate unit in the slope model (note that the name will change in your navigation tree also).

The Failure criterion can be toggled between Mohr-Coulomb, Generalised Hoek-Brown, or Bedrock. Bedrock is a unit that limits the extent of slope failure. The Anisotropy tab is available to define the anisotropic nature of Mohr-Coulomb cohesion and friction angle properties if they vary by direction, by default all properties will be considered isotropic.

The unit weights for Unsaturated (dry) and Saturated material can be adjusted.

Depending on the Failure criterion you have selected, you will be able to modify or accept the required settings (you may need to scroll down to see them all).

_		
⊟	Generalised Hoek-Brown	
	Intact comp. strength (kPa)	1000
	GSI (1-100)	20
	mi (1-50)	10
	Disturbance, D (0-1)	0
	Calculated Properties	
	m_b	0.5743
	5	0.0001379
	a	0.5437
	Uniaxial comp. strength (kPa)	7.962
	Tensile strength (kPa)	-0.24013
	Rock mass strength (kPa)	81.214
	Mod. Deformation, Em (kPa)	1.7783e+05
	Save to file	
	Mohr Coulomb Fit	
	Slope height (m)	10
	Max confining stress (kPa)	1e+05
	Cohesion (kPa)	1013.8
	Friction angle (deg)	2.08
L		V

If additional material units are required in the slope model they are added by right mouse clicking on the *Materials* item in the navigation tree and choosing Add material.

The material properties for each new unit can be entered in the same manner as above.

4. Surface data input



The project Surfaces define the geometry for one or more slope cases. Up to three physical Surfaces may be required for a slope stability problem, but the top and basal surfaces must be defined. The phreatic surface is optional.

Top Surface

One top surface must be created before any other data is added to the project. This defines the extents of the current project; all other surfaces should have some overlap with this top surface from a horizontal plan point of view. More than one top surface may be added if modelling of excavation or filling is required. The top surface used in your slope case can be a single surface or a composite defined from many surfaces.

Editing surfaces

All surfaces will initially be created in locked mode. If you require to edit their geometry you must first unlock them, this can be done by either un-ticking the Is Locked box in the geometry section of the *Surface* input panel or from the options when you right mouse click on the surface in the navigation tree. Your surfaces should be relocked to prevent any accidental shifting or adjustment once you have completed any editing.

Ī	✓ 🔚 Surfaces ✓ 🖳 Top						
	Basal 1 Plane						
	Ξ	Plane Surface	~	Show	^		
		ld		is Locked			
E.		Label		Delete			
		Туре		Duplicate			
		Kind	_	Top surrace			
	Ξ	Geometry					
		Is locked					
	Ξ	Point (m)		(0, 0, 0)			
8 H.		×		0			

Surface styles

The name/label and display style of the surface features can be adjusted while the surface is locked. This is done in the *Surface* input panel.

If a GeoImage has been loaded, it can be draped across the Top surface. The Colour can be reset by clicking the mouse button on the 3-dot icon at the right and selecting from a separate colour chooser dialog box or adjusting the numerical RGB components. The Opacity or transparency of the surface can be adjusted to allow the user to see through the surface to the surfaces below, the lower the value the more transparent the surface (minimum value is 25). The options for Surface representation are: Surface, Wireframe and Points. The options for Shading are:

Flat, Gouraud, Phong (different methods of shading, that for the most part will result in very similar look). Again, a dropdown box of these options is available with a mouse click in the right cell. The next two options in the **Surface** input panel control the surface or contour visualisation. These displays are controlled by toggling the tick icon or within the right mouse click options.

I	d	1
L	abel	Topography
T	уре	Cloud of points
K	Gind	Top Surface
+ 0	Geometry	
ΞS	urface style	
0	GeoImage	None
C	Colour	(30,200,60)
C	Dpacity	100
S	urface representation	Surface
S	hading	Flat
S	how surface	•
s	how contours	v

Creating surfaces

To create or import the top surface (usually topography) right mouse click the **Surfaces-Top** item in the navigation tree for the options:

- Add Extruded section
- Add Cloud of points (ASCII xyz)
- Add Plane
- Add Cone
- Add Biplanar surface
- Add Surface file import (obj, dxf, stl, vtp, xml)
- Add Composite

Cloud of Points or Surface file import.

The topographic surface is likely to have been modelled in another software package. These data may be contour or gridded values but require X Y Z components. If data import is via an external file then use the *Cloud of points* or the *Surface file* options. A file input dialog box will appear so the user can select the desired file.

➔ After file selection the points will appear in the Import Points dialog box, you must click OK to continue.

Import points: [kb_dtm.bxt] ×									
File r	ame:	C:\Use	ers\miran\Do	ocuments\TA	GASOFT	TSLOP	E\karaka\l	kb_dtm.txt	
	Help:	Select	columns for	r X, Y, Z					
Enco	dina:	ascii		7					
Duri	anng.	whiter							
Delii	miter:	writtes	pace *						
Skip number of	lines:	0							
Comment ch	ar(s):								
Point Colour	RGB:	RGB U	ndefined	\sim					
		x	Y	Z					^
1	1767	190	5919795	27.00					
2	1767	192	5919795	27.00					
3	1767	194	5919795	27.45					
4	1767	196	5919795	28.00					
5	1767	198	5919795	28.37					
6	17672	200	5919795	28.66					
7	17672	202	5919795	29.00					
8	17672	204	5919795	29.45					
9	17672	206	5919795	30.00					
10	17672	208	5919795	30.50					
11	17672	210	5919795	31.00					
12	17672	212	5919795	31.46					
13	17672	214	5919795	31.74					
			C01070C	22.00					
14	17672	216	2919/92	32.00					

If you are importing from a dxf file, and there are multiple layers in your dxf file, you will get a Select DXF layer dialog box requesting you select which layer in your dxf file that should be used to generate the Top surface. You will note that all layers within the dxf file will have been converted into vtp files in the folder containing the dxf file.

It is recommended that you limit the area of the surfaces that you import into TSLOPE to the area of interest for your slope stability problem. The project dimensions are set to accommodate the full range of X Y Z values that are loaded into the system. Project clipping (in the Preferences tab) can be used be trim the display of the area of interest, but all surfaces outside this are still retained in your project and will affect the size of your file when loading or saving.

Data imported are rendered using a Delaunay triangulation and will be displayed as a surface in the graphics panel.



If the number of faces is high, you may get a message recommending you decimate the surface. To do this you can right click on the surface in the navigation tree and select Decimate, you can then select the reduction percentage and after decimation you can save the surface to a new file.

V Surfaces							
🗸 🔚 Тор							
1: kb_dtm.txt							
🗸 🔚 Basal		1 Cloud of points					
🔀 2: slide_		Chann					
🔤 📝 3: slide_	~	snow					
V 🔚 Phreatic	~	is Locked					
4: piezo		Delete					
🗸 🔚 Geolmages		Decimate					
/// Geolma							
Decimate Surface ((1) 1.1	de dem tut		×			
Decimate surface ((1) 1:1	ko_atm.txt					
Input file	[2:\Users\miran\Documents\T	AGASOFT\TSLOPE\karaka				
T							
larget Reduction (1-9	19%)	71 🖶					
		i Decimate	Cancel				
				_			
Input:	7			^			
num faces = 70790	·						
Output:							
num points = 10825	5						
num faces = 20529							
Flansed = 0.36 sec.	6						
				-			
		Save Decimated	Surface				

Plane

The *plane* is the simplest surface, a single planar surface of any dip angle and bearing. To edit the geometry, unlock the surface, then manually set any of the dip angle, dip bearing, origin point and side lengths in the *Surface* input panel. Or adjust

them graphically in the graphics panel using the nodes. The circular nodes will lengthen/shorten the sides. The arrow node will adjust the dip angle and bearings.



Biplanar surface

A **biplanar surface** is a hinged surface comprising 2 planar surfaces. Again, it can be edited by manually entering values in the **Surface** input panel or manipulating the coloured nodes. For this surface type, the dip angle and bearings can only be edited in the **Surface** input panel. The outer nodes control the size of the bi-plane while the centre node raises and lowers the surface.



Extruded section

When adding a surface as an *Extruded section,* (as might be the case when working off a 2D cross section), you can manipulate the default section plane, by adding or importing the profile points with the X,Z pairs to create the section you require.



The overall width, section bearing and origin can also be manually entered or adjusted using the nodes. The outer node will lengthen/shorten the section, the middle node will rotate the section and the inner node will move the section up/down.



Cone

The **Cone** is manipulated as for the other surfaces by moving the coloured nodes to expand, rotate, and move the model into position, or by altering the values in the **Surface** input panel.



Composite surface

A **Composite** surface allows for combination of two or more surfaces, such as a topographic surface, and a designed cut slope.

	Composite Surface					
le	ł		3			
L	abel		Top Composite 3			
Т	уре		Cor	nposite		
K	ind		Top Surface			
ld	Туре	Label		Include	Required	
1	Cloud of points	1: kb_dtm.txt				
2	Plane	Top Plane 2				

The *Composite* surface input screen will display all defined top surfaces, you can tick to include as many of them as you wish to use. For top surfaces the lower most point from the included surfaces will be used in the composite surface – using a concave up logic.

The 'Required' box should be ticked if you wish to limit the composite surface to the extent of one or more of the surfaces. Your surface will still be valid if you do not tick any box in this column.

Using the right mouse click on any given surface in the navigation tree will give you the options to toggle display of the surface on/off, lock/unlock the surface, duplicate or permanently delete the surface (note that any surface used in a composite surface cannot be deleted and the surface must also be unlocked to be deleted).



In the image above the navigation tree is highlighted at

- > Surfaces
 - > Top
 - > Topography (the icon on the left indicates import mode of the data)

Basal Surface

At least one basal surface (a possible failure surface) must be defined before a slope case can be created. There is an exception for 2D slopes for critical search; a basal sphere will be automatically created for this type of analysis.

The **Basal** (failure) **surface** can be defined or imported in a similar manner to the Top surface options. They include:

- Add Extruded section
- Add Cloud of points (ASCII X Y Z)
- Add Plane
- Add Ellipsoid
- Add Log-Spiral
- Add Parabaloid
- Add Wedge
- Add Surface file import
- Add Composite

The *Ellipsoid, Log Spiral and Paraboloid* all follow the same methodology as for the surfaces described above. The choice of using one of these types of basal surface will depend on the slope problem that is to be analysed.

Ellipsoid





Paraboloid



Wedge



In the case of the Basal wedge option the coloured nodes allow scaling of the wedge and movement up and down, but the orientation of each side of the wedge is

controlled from the **Basal Wedge** input panel – you will need to scroll down to access. This is so measurements taken in the field can be applied. Separate material properties can be set for each side of the wedge when 'Use planar materials' is set to True.



A **Composite** surface allows for combination of two or more surfaces to form a basal shear surface that will define a 3D potential failure volume.

Selection of surfaces to be included is by a simple tick in the Include column. When 'Use sub-surface materials' is set to True the material property that is defined for each surface will be used, otherwise you can assign a single material to the **Composite** surface.

For basal surfaces the upper most point from the included surfaces will be used in the composite surface – using a concave down logic.

Composite Surface							
	ld			9			
	Lab	el		Bas	al Composi	te 9	
	Тур	e		Co	mposite		
	Kin	d		Bas	al Surface		
	Use	sub-surf	ace materials	Tru	e		
ld 3		Type Surort	Label 3: ew_fault.obj		Include	Required	^
4		Surort	4: ne_fault.obj		\checkmark		
5		Surort	5: nw_fault.obj		\checkmark		
6		Surort	6: sw_fault.obj		\checkmark		
7		Clonts	7: south_fault.xyz		\checkmark		
8		Surort	8: mainseamroof.dxf		\checkmark		
10		Surort	10: mainROOF.vt	p			~

Phreatic Surface

Phreatic surfaces define the location of the water table. This is used to define the dry and saturated weights of the columns, and if a pore-pressure surface is not defined, it is also used to set the pore-pressure at the basal surface.

Phreatic surface/s can be defined or imported in a similar manner to the other surfaces. The available methods are:

- Add Extruded section
- Add Cloud of points
- Add Plane
- Add Biplanar surface
- Add Surface file import
- Add Composite

Geolmages

A **Geolmage** is an image (JPEG, PNG, TIFF), such as an aerial photograph, with associated coordinate information that may be used to drape over a surface.

To view a GeoImage, select a *Top Surface* to map the GeoImage on, and select the GeoImage item in the selected panel's Surface Style section.

Boundary lines

A **Boundary line** is a 2D polyline that is associated with a top surface. The boundary line may be a tension-crack line that has been observed in the field, and may be closed or open ended. For some slopes, movement may be sufficient to define a closed boundary line that combines: a tension-crack, a side shear line, and a thrust line at the base of the slope.

The X,Y Points defining the boundary line can be typed in manually or imported from external file. Where you have defined multiple top surfaces, you can chose which surface to apply the boundary line to.

	Boundary Boundary Layers Zones Loads	ines sryLine 1		Points	1	×
	Cross-sections		~	X (m)	Y (m)	Add
⊟	Boundary line 1					Incert
	Label	BoundaryLine 1				mastr
	Points (m)					Delete
	Closed?	False				llo
	Apply to surface	None				Op
⊟	Display Properties					Down
	Show line	v				File import
	Colour	Red				rite import
	Line width (pixels)	3		ОК	Car	ncel

The use of a boundary line for a slope-case is optional.

5. Layer data input



A *Layer* surface allows material properties to be defined as layered strata. The layer surface defines the top of the extent of the assigned material properties; the material properties are assumed to be constant below this layer surface, until another layer surface is encountered. The *Layer* surfaces must not cross through each other. The region above the highest layer surface has the material properties as defined by the 'Default Material'.

Depending on the slope stability problem there are options to refine the analysis by adding specific layers to the model that can have different material properties.

For the definition of layers TSLOPE works with the top of each layer. We assume that the user will have used a geological modelling system for complex problems, and the appropriate checks will have been made that there are no stratigraphic anomalies.

TSLOPE assumes that the properties associated with each layer extend with depth below the top of each layer until the top of the next lower layer is reached.

To add a Layer right mouse click the *Layer* item in the navigation tree to reveal the options for importing a layer surface

- Add Extruded Section
- Add Cloud of points (ASCII XYZ)
- Add Surface file import
- Add Plane
- Add Composite

These layer surfaces are added and modified in the same way as the surfaces detailed in the previous section.

The layer surfaces do not have to match any of the other surfaces already defined in your project

6. Zones data input



A **Zone** is defined by a horizontal non-intersecting 2D polygon. The zone is used to assign material properties for a 3D volume as defined by the vertical extrusion of this zone.

All columns that have their centres pass through the zone are assigned the material properties associated with that zone.

If there are any regions not covered by a zone, the material properties will be that given by the 'Default Material'.

If you define multiple zones and any do intersect, the properties for the zone you defined first will take precedence and be used for any columns with centres inside the overlap.

To activate the Zone input, right mouse click on the Zone item in the navigation tree and Add zone ...

In the **Zone** input panel, the **Label** can be renamed. The points defining the zone can be initiated by clicking in the Boundary points (m) cell which produces the Zone Boundary Points dialog box. Points can be entered manually or imported via The File Import option. The file is ASCII format (X Y (ID is optional)). Imported points will appear in the dialog box. Click OK to proceed.

In the Zone Boundary Points dialog box, the Add button will create a new boundary point, the Up/Down buttons will allow the selected boundary point to be moved either up or down in the list. Delete will remove the highlighted point, while Insert will insert a new row into the list. It is not necessary to enter a closing point, the zone will automatically close back to point 1. If there is no display of your zone in the graphics panel you should check that the points are in a logical order to define the boundary.

The Colour, Opacity, and visibility parameters can be set. Material properties for each zone can then be defined under the Surface style section in the **Zone** input panel.

The height of the zone/s displayed in the graphics panel are initially created with an offset from each other, they can be adjusted by moving the coloured node which is visible along the Z axis, note that if you edit the height then all zones you have created will be adjusted to that new height.

7. Loads



The types of loads that may be added are: point loads, vertical uniform loads and seismic pseudo-static loads.

A load case defines a combination of the currently defined loads. By default, the load case 'None' is assigned to a slope. This load case does not include any loads.

Point load

A **Point load** defines a load acting at a specified 3D point. Location, direction, bearing and dip values can be adjusted graphically in the graphics panel by moving the nodes or manually entered in the point load input panel. The magnitude of the load must be entered manually. The degree of influence of the 3D load onto a cross-section will depend on many factors, including distance of the cross-section from the 3D point load, it is therefore necessary to also enter the 2D magnitude if you are running a 2D slope case (this may need to be adjusted for different cross-sections).

Ξ	Point Load 1				
	Label	Point load 1			
⊡	Location (m)	(50, 0, 100)			
	Х	50			
	γ	0			
	Z	100			
	Magnitude (kN)	1			
	Magnitude 2D (kN/m)	1			
	Bearing (deg.)	0			
	Dip (deg.)	90			
	Direction vector	(0, 0, -1)			
	Х	0			
	γ	0			
	Z	-1			
\square	Appearance				
	Colour	(153,0,51)			
	Opacity	60			
	ls visible?	✓			

Vertical uniform load

A **Vertical Uniform load** acts over a horizontal region defined by a 2D boundary polygon. The load boundary points can be entered manually or imported from external file into the load boundary points dialog box. The magnitude of the load that will be applied uniformly across the entire region must be entered manually. The elevation of the load should be set so that it is above the basal surface, if it is below the assumed failure surface (and the load is downwards), then the load will not have any effect to the stability of the slope. For visualising the load, the display height can be adjusted from the defaults.

Ξ	Vertical Uniform Load 2							
	Label	Load 2 (Vertical Uniform Load)						
	Magnitude (kPa)	1						
	Elevation (m)	0						
	Display height (m)	3						
	Boundary points (m)							
\square	Appearance							
	Colour	(178,0,76)						
	Opacity	90						
	ls visible?	✓						

Seismic load

A **Seismic load** is defined using a pseudo-static approach. The horizontal component may either act in the critical direction of sliding as determined for the static case, or in a user-defined direction.

Ξ	Seismic Load 3						
	Label	Load 3 (seismic load)					
	Horizontal seismic coefficient, kh	0					
	Vertical seismic coefficient, kv	0					
	Use critical sliding direction?	True					

Load case

A *Load case* defines the load you wish to apply during slope analysis – it may contain just a single load, or a combination of the currently defined loads. Multiple point or vertical uniform loads can be selected in a load case, but only one seismic load (or none) may be assigned to a load case.

If you have included any point loads, the influence angle can be adjusted. The influence angle is used to set a circular zone of influence that expands out with distance from the location point where the point load is applied.

During slope analysis all the loads in your load case will be applied simultaneously.

	Load Case 1							
	Label	Load-case 1						
	Point loads Influence angle (deg)	45						
	Seismic load	None						
Ξ	Point loads							
	1: Point load 1							
⊟	Vertical Uniform Loads							
	2: Load 2 (Vertical Uniform Load)							

8. Cross-sections



TSLOPE also provides 2D slope analysis along a defined cross-section. To define a cross-section highlight **Cross-sections** in the navigation tree and right mouse click to Add cross-section. You can add as many cross-sections as you need. The right mouse click menu on **Cross-sections** also allows you to Hide all or Show all, rather than individually toggling their visibilities.

To orient the section through the model to the desired location move the end point nodes in the graphics panel. One node acts as an anchor and the other changes the length and orientation. Alternatively, you can manually enter the values for Start point, End point, Bearing and Length in the input screen.

For any defined cross-section, you can right mouse click to get some more options. You can toggle visibility for that section, add a new section based on the set up for the chosen section, delete, reverse direction (which swaps the start & end points and recalculates the bearing).

The last option is to Add 2D slope using this Cross-section. This will open a dialog box allowing you to create a new 2D slope and is covered in more detail in the following section.



9. Slope Analysis

A project may consist of one or more slope cases. Multiple slope cases allow parametric studies to investigate the stability of slopes when aspects of the slope vary, eg material properties, pore pressure and phreatic surface changes, and any other parameter of interest. Once the Material properties, Layers and Zones have been defined and the Surfaces included then the slope analyses can be conducted. Phreatic and pore-pressure surfaces are optional.

To define the parameters for a slope analysis, highlight the **Slope Cases** item in the navigation tree and right click to add a new slope case. You can select between 3D or 2D slope analysis. The slope analysis components are similar in both dialog boxes for 3D and 2D analysis, you need only to have defined a cross-section line for the 2D analysis.

_			T.	Create new Slope	×	
ī	Create new Slope	×		Slope 9		
□ Slope 9				Label	Slope 9	
	Label	Slope 9 3D		Dimension	2D	
	Dimension			Cross-section	1: Central Cross section	
	Define Basal failure surface	One basal surface		Define Basal failure surface	One basal surface	
Ξ	Surfaces			Surfaces		
	Тор	1: Top		Тор	1: Top	
	Basal	2: Hemisphere		Basal	2: Hemisphere	
	Phreatic	None		Phreatic	None	
	Pore-pressure	None		Pore-pressure	None	
E Loads				Loads		
	Load case	No Loads		Load case	No Loads	
Ξ	Slope Clipping			Slope Clipping		
	Enable clipping	False		Visual Properties		
Ξ	Visual Properties			Min. z	100	
	Min. z	100		Background colour	White	
	Background colour	White				
	ОК	Cancel		ОК	Cancel	

Define Basal failure surface:

Slope 9						
Label	Slope 9					
Dimension	2D					
Cross-section	1: Central Cross section					
Define Basal failure surface	One basal surface 🗸 🗸					
Surfaces	One basal surface					
Тор	Basal surface clipped by layer					
Basal	Layer clipped by boundary line					

- One basal surface: for this you must select from any of the Basal surfaces you have defined, it can of course be a composite basal surface.
- Basal surface clipped by layer: for this you need to select both a Basal surface and a Layer as basal and your basal surface will be clipped back to that layer.

• Layer clipped by boundary line: in this case you need to select your Layer as basal and the Boundary line then enter details of the boundary line angles.

_		
	Define Basal failure su	Layer clipped by bour 🗸
\square	Surfaces	
	Тор	1: Top
	Phreatic	None
	Pore-pressure	None
	Layer as basal	None
\square	Boundary line	
	Boundary line	None
	Crest dip (deg.)	60
	Toe dip (deg.)	60
	Sliding bearing (deg.)	270

Surfaces

Top, Basal and Phreatic surfaces can be chosen from the selection box in each cell – only valid surfaces will be shown in each selection. For some cells there is the option to select None, though if the surface is required you will get a message before you can continue with the slope case.

If you define a Phreatic surface you will get some additional options:

- Use phreatic correction?
 - False no correction used.
 - True this applies an approximate correction by estimating the piezometric head from a flow net type analysis.
- Clamp phreatic to top?
 - False uses the modelled phreatic surface over entire slope case.
 - True this will set your phreatic surface to match your top surface,
 - where the modelled phreatic surface extends above the top surface.
- Clamp z (m)
 - If you have selected to clamp your phreatic surface, you can offset your top surface by Xm so your phreatic surface will match your top surface – Xm where it extends above that line.

If you know the pore pressure ratio for the project you can enter that

- Pore-pressure
 - False this will use the default value of 0
 - True you enter the ratio (it must be between 0 and 1)

Loads

You can select a load case to apply if any have been defined. It is often useful to have create a slope case or scenario with the load case and one without to see the difference it makes.

Other parameters

3D analysis will give you the option to enable clipping, to clip the surfaces back further than the already defined boundary (like project clipping). It is recommended that you use slope clipping to reduce the number of columns that are outside the slide boundary to get a better definition of your 3D slope case. This will modify the volume that is discretised into columns during the analysis. Slope clipping can also be used to remove spurious columns that might be artefacts of modelling of surfaces.

Visual properties are also able to be set, these include a minimum z value and the background colour (which will default to the colour set in your preferences).

When you click OK in the dialog box your slope case will be added to the navigation tree and a new tab will be created in the graphics panel (across the top of the panel) as shown in the figure below. For a 3D slope case the gridded view of the model

shows the columns involved in the stability analysis in a darker shade, this view can be orientated in the same way as your project setup. A 2D slope case will show just the section line and is not able to be rotated, but you can zoom and pan the graphics.



When the Slope Case is selected the *Slope Case* item panel has multiple tabs: Slope, Description, Materials and Analysis. You will also see an Apply and a Solve button at the top of the panel, or below the navigation tree.

The **Slope** tab will display the surfaces, loads etc as defined when you initiated the slope case. The **Description** tab allows you to input any notes or references about the slope case as required.

The *Materials* tab displays the material properties for the analysis. It will list the material definition being used (one material, layers or zones) and identify which material has been allocated to each layer, zone or basal surfaces. You can choose to override the default materials assigned to each of these by toggling 'Override default material assignments' to True and then selecting a different material.

The *Analysis* tab has multiple analysis parameters, they will initially populate with default settings. There are a few options, note that some may not appear in your list depending on what you have already defined for your project and/or slope case.

- Analysis Type
 - Defined surface analysis
 - user defined top and basal (failure) surfaces,
 - calculates a factor of safety.
 - Critical search (2D slope cases only)
 - user defined top surface only,
 - a search is made for the critical circle with minimum factor of safety,

- the critical circle surface is saved as a basal surface in the navigation tree.
- o Back-analysis
 - user defined surfaces,
 - iteratively carries out a number of analyses with varying strength parameters (Mohr-Coulomb, or Hoek-Brown),
 - generates a cross plot with contours of factor of safety.
- Yield acceleration analysis
 - user defined surfaces,
 - searches for the horizontal seismic acceleration (due to earthquake) that gives a factor of safety of one.
- Solution-space analysis (3D slope cases only)
 - this gives a 3D view of the side force angles to show how calculated factor of safety varies, and check that the appropriate minima has been reported.
- Method
 - o Ordinary
 - Spencer's
- Expected FS
 - If known, enter the expected factor of safety
- Materials definition
 - One material
 - o Layers
 - o Zones
- Use Basal Surface Material
 - False this will assume the material properties on the basal surface are your default properties, or match those of the layer or zone the basal surface point lies within.
 - True this will use the material properties for the material that has been set in the Surface input panel for your basal surface, these will apply to the entire basal surface irrespective of the layer or zone the surface lies in.
- Tension crack definition
 - \circ None
 - Depth this will generate a new set of parameters defining the depth and fluid levels in the tension crack, they can be adjusted from defaults if necessary.

The 3D column grid and 2D slice parameters allow you to increase or decrease number or size of columns or slices. The larger the number of columns or slices, the longer the processing time. In the 3D option, you can also align the grid to a different bearing. At times, the Apply button may display red when you have adjusted a parameter that is not yet reflected in the graphics panel for your slope case.

To commence the analysis for a slope case, click on the **Solve** button. A new **Results** tab will appear in the **Slope Case** item panel. When any of the material properties are changed then click the **Apply** and **Solve** buttons for an updated analysis.

10. Analysis Outputs

Some of the results of the analysis can be displayed graphically in the graphics panel. To view the various outputs, select from the *Data* menu at the top. You will get different options for 2D and 3D slope cases.

3D outputs include:

- None
- Total Normal Stress
- Effective Normal Stress
- Pore Pressure (where a Phreatic surface has been included)
- OMC Local FS
- Is Tension Crack

All graphical results appear in the graphics panel when the type has been selected. To assist with viewing and understanding the outputs, the various surfaces and layers in the slope case can also be toggled on/off from within the View tab.



In the case of a 3D analysis the Local Factors of Safety output produces a colourcoded model based on the number of columns used for the analysis and a directional vector with an overall FS value (see Figure below). The coloured cells are mapped to the basal surface, so best viewed with top and/or phreatic surfaces toggled off.



The *Results* tab in the *Slope Case* item panel itemises the key analysis parameters.

2D outputs include:

- Measure distance
- Save column data as CSV file
- Display trust line
- Display effective normal stress
- Display basal pore pressure
- Display top water pressure

The graphical display of the 2D slope case shows the thrust line (red), the effective normal stress (black arrows), and the basal pore pressure (blue arrows). These may be toggled off, or on as required from the **Data** menu. If there are tensile interslice forces, then those slices will be coloured red as a warning.

To interrogate the data graphically, position the mouse at a relevant point (usually the centre of the slice where it intersects a surface), and use Ctrl left mouse click, or hotkey 'P' to get the display below. A further Ctrl left mouse click or hotkey will remove that information.



11. Reporting

There are a number of features which enable the user to easily capture the graphical outputs for inclusion in a report.



Using the options on the tool bar you can:

Copy to Clipboard

This will copy your entire graphics panel view in its current size and proportions to the clipboard to be pasted into another document. (View > Copy will do the same thing).

Save Image to File This allows your graphics panel to be saved as a png file, it will save only to the extent of the text or image rather than the entire view. (View > Save view... will do the same thing).

• Take Image for Report

This will save a copy of the current graphics panel view into the Report Snapshots tab at the bottom of the graphics panel. Multiple views can be saved in this manner, captions can be added to them in the report snapshots tab.

<u></u>		٠		*	10	k	<u>,</u>		Ē,	2	O
New	Open	Save	Preview	Print	Show BB	Show Axes	Zoom Extents	Sync Views	Сору	Save Image	Snapshot

A summary report is automatically generated and can be previewed using the Print Preview icon from the quick tool bar.

Alternatively, you can use File > Print Preview Report.

Any report snapshots associated with the slope cases will be included in the summary report which lists all the surfaces and material properties as well as all the slope cases analysed.

The report can be printed or exported under the File menu

File > Print Report...

File > Export HTML Report...

See notes on Export HTML Report-Embed Images in the preferences section of this guide if you have problems with the images saving to your document.

The Data menu opens to allow selection of Save column data as CSV file ...



A CSV file will be opened in the current directory and allow the user access to all the column (or slice) data.

Appendix 1. Wedge and Tension Crack

This a theoretical example to demonstrate how to construct a biplanar top surface and a basal wedge with a tension crack and then analyse the slope stability of this model.



The default material properties have been accepted and no layers or zones are used.

A Surface for the Top is defined by adding a biplanar surface. The surface automatically appears in the graphics panel. The shape of the surface can be manipulated using the coloured nodes which control the length and width of each plane but these parameters can also be set manually in the **Surface** input panel on the left. The Dip of each plane is set manually. In this case the parameters of the surface have been adjusted to match the Heok and Bray example

Once the surface dimensions are finalised it is advisable to click the Is Locked box before adding the Basal surface.



The Basal surface in this theoretical example is a Wedge.

Like the biplanar surface the wedge will automatically appear in the graphics panel. The coloured nodes at the outer edges of the wedge control the width of each side, the lower central node raises or lowers the wedge and the upper/rear central node increases or decreases the length of the wedge axis.

The dip and dip bearing of each side of the wedge is set manually in the **Basal Wedge** input panel. The other dimensions for each side of the wedge can also be set manually as well as the selection of which material properties are associated with each side of the wedge.

There is an option to add a tension crack to the wedge. At the top of the **Basal Wedge** input panel the *Include tension crack plane* by default is set to false. To add a tension crack toggle the false to true.

As with the previous constructs of the model the tension crack will automatically appear within the wedge when set to true.

The tension crack has a node at the base of the wedge which moves the tension crack plane forward or back within the wedge. The *Dip* and *Dip bearing* can only be adjusted in the **Basal Wedge** Input Panel.

Once the tension crack has been added the material properties may need revisiting. In this case the *Cohesion* and *Angle of friction* for each side of the wedge have been modified to reflect the Hoek and Bray example (1977 pg 334).

When all he surfaces and elements for the model have been defined it is time to build a slope case.

When adding a Slope Case, we have selected 3D in this example, the slope panel will adopt the Top and Basal surfaces that have already been defined. If there is more than one top or basal surface then the user will need to select the required ones. In the *Slope Case* item panel under the Analysis tab there is an option to increase or decrease the number of columns, you may need to increase the number of columns to remove gaps at the edge of the model.

Then SOLVE

The Slope Case panel now has a Results tab with includes both the Spencer's and Ordinary results.



References

Heok, E.; Bray, J.W. 1977. Rock Slope Engineering. Revised Second Edition. *Institute of Mining and Metallurgy*.